







Download Manual

### Shenzhen Growatt New Energy CO.,LTD

No.28 Guangming Road, Shiyan Street, Bao'an District, Shenzhen, P.R.China

**T** +86 755 2747 1942

E service@ginverter.com

W www.ginverter.com

GR-UM-212-A-02



Installation

&

**Operation Manual** 

# Index

6.8 Inverter demand response modes

(DRMS)

6.9AFCI(Optional)

1 Notes on this manual 1.1 Validity 1.2 Applicable personnel 1.3 Symbols in this document 2 Safety 2.1 Product description and features 2.2 Qualification of skilled person2.3 Safety instruction 3 Product overview 3.1 Appearance overview 3.2 Dimensions 3.3 Storage environment 4 Unpacking inspection 5 Installation 5.1 Basic installation requirements 5.2 Mounting wall mount 5.3 Installing the inverter 6 Inverter wiring 6.1 Security 6.2 AC side wiring 6.3 DC side wiring 6.4 Connect the signal cable 6.5 Grounding the inverter 6.6 Active power control with smart meter,CT or ripple control signal receiver 6.7 GFCI(Standard)

7 Debugging		13 Troubleshooting	13.1 Error message 13.2 Syetem error
8 Working mode	8.1 Normal mode 8.2 Failure mode 8.3 Shutdown mode	14 Manufacturer warranty	
9 OLED display and touch buttons	9.1 Boot display 9.2 OLED display wake up 9.3 Function setting	15 Decommissioning	15.1 Dismantling the inverter 15.2 Packing the inverter 15.3 Storing the inverter 15.4 Disposing of the inverter
10 Communication and monitoring	10.1 RS485 10.2 USB-A	16 EU declaration of conformity	
11 Maintenance and Cleaning	11.1 Checking heat dissipation 11.2 Cleaning the inverter 11.3 Checking the DC disonnect	17 Specification	17.1 Specification 17.2 Torque 17.3 Annex
12 Start the inverter and shut down the inverter	12.1 Start the inverter 12.2 Shut down the inverter	18 EU declaration of conformity	
		19 Contect us	

# 1 Notes on this manual

# 1.1 Validity

This manual will provide detailed product information and installation instructions for users of model TL3-X series photovoltaic inverter of Shenzhen Growatt new energy Co., Ltd. (hereinafter referred to as Growatt new energy). Please read this manual carefully before using this product. Growatt new energy will not inform users of any changes to this manual.

MOD 3000TL3-X

MOD 4000TL3-X

MOD 5000TL3-X

MOD 6000TL3-X

MOD 7000TL3-X

MOD 7000TL3-X-AU

MOD 8000TL3-X MOD 8000TL3-X-AU

MOD GOOGTLS-X-

MOD 9000TL3-X

MOD 9000TL3-X-AU

MOD 10KTL3-X

MOD 10KTL3-X-AU

MOD 11KTL3-X

MOD 11KTL3-X-AU

MOD 12KTL3-X

MOD 13KTL3-X

MOD 15KTL3-X

# 1.2 Applicable personnel

The inverter must be installed by professional electricians who are certified by relevant departments. By reading this manual in detail, the installer can install the MOD TL3-X series inverter correctly and quickly, and can carry out troubleshooting and communication system construction.

If there are any problems during the installation process, the installer can log on to www.growatt.com to leave a message on the website or call our 24-hour service phone:+86 755 2747 1942.

# 1.3 Symbols in this document

#### 1.3.1 Symbols in this document

Warnings indicate hazards to equipment or personnel. It draws your attention to a certain procedure or practice. If the procedure or practice is not properly implemented or followed, it may cause damage or destruction of part or all of the Growatt device and/or other equipment connected to the Growatt device, or cause personal injury.

Symbol	Description		
DANGER	<b>DANGER</b> indicates a hazardous situation which, if not avoided, will result in death or serious injury.		
WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.		

CAUTION	<b>CAUTION</b> indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	NOTICE is used to address practices not related to personal injury.
i Information	Information that you must read and know to ensure optimal operation of the system.

#### 1.3.2 Markings on this product

Symbol	Explanation	
4	Danger: Electricity!	
	Danger:Flame!	
	Danger: Hot surface!	
Smin	Operation after 5 minutes	
	Point of connection for grounding protection	
	Direct Current (DC)	
$\sim$	Alternating Current (AC)	
i	Read the manual	
(€	CE mark. The inverter complies with the requirements of the applicable CE guidelines.	
X	The inverter must not be disposed of with the household waste.	

# Safety 2

#### 1.3.3 Glossary

#### AC

Abbreviation for "Alternating Current"

#### DC

Abbreviation for "Direct Current"

#### Energy

Energy is measured in Wh (watt hours), kWh (kilowatt hours) or MWh (megawatt hours). The energy is the power calculated over time. For example, your inverter operates at a constant power of 4600 W for half an hour and then at a constant power of 2300 W for another half an hour, it has fed 3450Wh of energy into the power distribution grid within that hour.

#### Power

Power is measured in W (watts), kW (kilowatts) or MW (megawatts). Power is an instantaneous value. It displays the power your inverter is currently feeding into the power distribution grid.

#### Power rate

Power rate is the radio of current power feeding into the power distribution grid and the maximum power of the inverter that can feed into the power distribution grid.

#### Power factor

Power factor is the ratio of active power or watts to apparent power or volt amps. They are identical only when current and voltage are in phase then the power factor is 1.0. The power in an ac circuit is very seldom equal to the direct product of the volts and amperes. In order to find the power of a single phase ac circuit the product of volts and amperes must be multiplied by the power factor.

#### PV

Abbreviation for photovoltaic.


#### Wireless communication

The external wireless communication technology is a radio technology that allows the inverter and other communication products to communicate with each other. The wireless communication device is not standard. Require to order extral if you need it.

## 2.1 Product description and features

#### 2.1.1 Product description

Growatt series photovoltaic inverters are used to convert the direct current generated by photovoltaic panels into alternating current, and send it to the grid in a three-phase manner. Growatt MOD 3-15K TL3-X series inverter can be connected to 2 strings (12-15K TL3-X and 7-11K TL3-X-AU can be connected to three strings), has 2 maximum power tracking point trackers, so suitable for connection 2 Set of arrays of different panels.



Position	Description	
A Solar panel		
В	DC circuit breaker	
С	Inverter	
D	D AC circuit breaker	
E Electric energy meter		
F	Utility grid	

As shown in Fig 1.1 above, a complete photovoltaic grid-connected system includes photovoltaic modules, photovoltaic inverters, public grids and other components. In the photovoltaic module system, the photovoltaic inverter is a key component. Note: If the selected photovoltaic module requires positive or negative grounding, please contact Growatt for technical support before installation.

#### 2.1.2 Product features

The characteristics of the inverter are as follows:

- > Dual independent maximum power point tracking
- Built-in DC switch
- > Compatible with RS485/Wifi/GPRS/4G communication
- > 140V-1100V input voltag range
- > The maximum efficiency is as high as 98.6%
- OLED+LED/WIFI+APP display
- Integrated with touch button
- Protection grade lp66
- The weight is only 16kg
- Simple installation

### 2.2 Qualification of skilled person

This grid-tied inverter system operates only when properly connected to the AC distribution network. Before connecting the MOD TL3-X to the power distribution grid, contact the local power distribution grid company. This connection must be made only by qualified technical personnel to connect, and only after receiving appropriate approvals, as required by the local authority having jurisdiction.

#### 2.3 Safety instructions

- 1. Please read this manual carefully before installation. If you fail to install according to the instructions in this manual, or ignore the warnings in the manual and the equipment is damaged.our company reserves the right not to guarantee the guality: 2. All operations and wiring should be finished by the professional electrical or mechanical engineers;
- 3. During installation, except for the wiring terminals, please do not move other parts inside the chassis;
- 4.All electrical installations must comply with local electrical safety standards:
- 5.If the machine needs maintenance, please contact the local designated system installation and maintenance personnel;
- 6. The use of this machine for grid-connected power generation requires permission from the local power supply department;
- 7. When installing photovoltaic modules during the day, use opaque materials to cover the photovoltaic modules otherwise the voltage at the module terminals will be high in the sun, which may cause personal danger.

#### 2.3.1 Assembly Warnings



- safety hazards.
  - Follow the instructions in this manual to assemble the inverter. Note that select the suitable mounting location and comply with the specified requirements of cooling.

> Before installation, pleae check the unit to ensure that there is no

transportation or handling damage, which may affect the insulation integrity or safety clearances; otherwise, it may cause

- Unauthorized removal of necessary protections, improper use, incorrect installation and operation may lead to serious safety and shock hazards and/or equipment damage.
- In order to minimize the possibility of shock hazards due to dangerous voltages, cover the entire solar array with dark colored materials before connecting the array to any equipment.



- CAUTION
- Grounding the PV modules: MOD TL3-X is a transformerless inverter, which means there is no galvanic separation. Do not arounding the DC side of the MODTL3-X inverter. Only grounding the mounting frame of the photovoltaic module. Otherwise there will be an error message "PV ISO Low".
- Comply with the local requirements for grounding the PV modules and the PV generator. GROWATT recommends connecting the generator frame and other electrically conductive surfaces in a manner which ensures continuous conduction with ground in order to have optimal protection of the system and personnel.

#### 2.3.2 Electrical Connection Warnings



DANGER

- The components in the inverter are live. Touching live components can result in serious injury or death.
- Do not open the inverter except the wire box by qualified persons.
- Electrical installation, repairs and conversions may only be carried out by electrically qualified persons.
- Forbid live line work.
- Danger to life due to high voltages in the inverter
- There is residual voltage in the inverter after the device shutdown. The inverter need to take 20 minutes to discharge for safety.
- Persons with limited physical or mental abilities may only work with the Growatt inverter following proper instruction and under constant supervision. Must keep the Growatt inverter away from children.



- WARNING
- Make all electrical connections (e.g. conductor termination, fuses, PE connection, etc.) in accordance with prevailing regulations. When using the inverter to provide the power, adhere to all prevailing safety regulations to minimize risk of
- Systems with inverters typically require additional control (e.g., switches, disconnects) or protective devices (e.g., fusing circuit breakers) depending upon the prevailing safety rules.

#### 2.3.3 Operation Warnings



- > Ensure all connectors are sealed and secure during operation.
- Although designed to meet all safety requirements, some parts and surfaces of inverter are still hot during operation. To reduce the risk of injury, do not touch the heat sink at the back of the PV-inverter or nearby surfaces while inverter is operating.
- Incorrect sizing of the PV panels may result in voltages being present which could destroy the inverter. The inverter display will read the error message "PV voltage High!"



CAUTION

All operations regarding transport, installation and start-up, including maintenance must be operated by qualified, trained personnel and in compliance with all prevailing codes and regulations.

- When the inverter is disconnected from the grid, please be careful because some components can retain enough charge to create a shock hazard. In order to minimize the occurrence of this situation, observe all corresponding safety symbols and marks in this manual.
- ➤ Under special circumstances, the inverter may be subject to electromagnetic interference from surrounding equipment. At this time, the user is obliged to take correct measures to reduce the interference from surrounding equipment to the inverter.
- > Do not stay close to the inverter less than 20cm at any time.

# Product overview 3

## 3.1 Appearance overview




Fig 3.1 The appearance instructions are as follows:

No.	Name	No.	Name
А	DC switch	E	AC terminal
В	PV terminal	F	LED indicator
С	RS485 port	G	LCD screen
D	USB port	Н	Touch button

#### The label description on the inverter:

LOGO	Description	Description
	Tap logo	Touch button: We can switch the LED display and set parameters by touching.
	Inverter status identification	Indicate the current running status of the inverter Red: fault Green: normal operation Flashing red light: warning Flashing green: update program

### 3.2 Dimensions




Fig 3.2

### Size and weight:

Model	Height (H)	Width (W)	Depth (D)	Weight
MOD 3-6KTL3-X	387mm	425mm	147mm	12.5kg
MOD 7-11KTL3-X	387mm	425mm	178mm	14kg
MOD 12-15KTL3- X & MOD 7- 11KTL3-X-AU	387mm	425mm	178mm	16.0kg

# 3.3 Storage Environment

If you want to store the inverter in a warehouse, you must choose a suitable location for the inverter.

- > The equipment must be stored in its original packaging.
- > The storage temperature should always be between -25° C and +60° C, and the storage relative humidity should be less than 90%.
- > If you need to store a batch of inverters, the maximum number of layers of the original carton is 4.

# Unpacking inspection 4 Before opening the inverter package, please check whether the outer package is

Before opening the inverter package, please check whether the outer package is damaged. After unpacking, please check whether the appearance of the inverter is damaged or lack of accessories. If there is damage or missing parts, please contact the dealer.




Fig 4.1

No.	Description	Qty.
А	Inverter	1
В	Quick Installation Manual	1
C	Wall mount	1
D	AC waterproof cover(just for Vietnam models)	1
Е	Datalogger	1
F	COM port signal connector	1
G	AC connector	1
Н	Waterproof connector(just for Vietnam models)	1
I	Plastic expansion tube	3
J	Expansion screw	3
K	Security screw	1
L	AC customer's terminal(just for Vietnam models)	5
М	PV terminal shell	3/3
N	PV terminal core	3/3
0	COM port removal tool	1
Р	PV terminal removal tool	1
Q	AC terminal block insulation partition(just for Vietnam models)	1

10

# 5 Installation

### 5.1 Basic installation requirements

- > The wall on which the inverter is mounted must be sturdy and can withstand the weight of the inverter for a long time (refer to the specifications in Chapter 17 for the weight of the inverter);
- > The installation location must match the size of the inverter;
- > Do not install the inverter on a building constructed of flammable or heat-resistant materials;
- > Install the inverter in an eye-view orientation to facilitate inspection of the OLED display and maintenance work;
- > The machine's degree of protection is IP66 and can be installed indoors and outdoors;
- > It is not recommended to expose the inverter directly to strong sunlight to prevent overheating and cause power derating;
- > The humidity of the installation environment should be between 0 and 90%;
- ➤ The ambient temperature around the inverter should be between -25 ° C ~ 60 ° C;
- > The inverter can be mounted on a plane that is tilted vertically or backwards. Please refer to the following figure:




Fig 5.1 Installation diagram

> In order to ensure the normal operation of the machine and the convenience of personnel operation, please pay attention to provide sufficient clearance for the inverter. Please refer to the figure below:

Direction	Minimum clearance (mm)
Above	500
Under	500
Both sides	300
Forward	300




Fig 5.2 Installation dimensions for one inverter




Fig 5.3 Installation dimensions for multiple inverters

- Do not install the inverter on the TV antenna, other antennas or antenna cables;
- Do not install the inverter in the living area:
- Do not install the inverter where children can reach it;
- > The inverter should be installed in a sheltered and protected location such as cool, rain-proof;

12




Fig 5.4 Installation Environment

Make sure that the inverter is installed in a suitable place and is not allowed to be installed in a closed box;




Fig 5.5 Closed box

> In order to reduce the inverter load and extend the life of the inverter due to direct sunlight, we recommend installing a awning. The distance between the awning and the inverter is as follows:




Fig 5.6 Sunshade

### 5.2 Install the wall mount

#### 5.2.1 Install the wall mount



To prevent electric shock or other damage, be sure to check the wall for power or other piping before opening the hole in the wall.




Fig 5. 7 Specifications of wall mount

Secure the wall mount as shown, do not let the screws flush with the wall, instead expose 2 to 4 mm.




Fig 5.8 Schematic diagram of wall mount installation

# 5.3 Installing the inverter


Note: Before installing the inverter, you must first make sure that the wall mount is firmly fixed to the wall.

steps:

- 1. Hang the inverter on the wall mount and keep the inverter balanced when hanging.
- 2.To ensure that the inverter can be securely attached to the wall, secure the side of the inverter with the M5 safety screw on the left.

# Inverter wiring 6

# 6.1 Security



# 6.2 AC side wiring

	Danger	Before making electrical connections, please make sure that the DC switch of the inverter is in the "OFF" state and disconnect the AC side MCB, otherwise the high voltage of the inverter may cause death.
	Warning	<ul> <li>Each inverter must be installed with an AC circuit breaker independently, and it is forbidden to share multiple inverters.</li> <li>It is forbidden to use single-core wire at the output terminal of the inverter.</li> <li>It is forbidden to use aluminum wires as output cables.</li> <li>Please ensure that the output cable is well connected before turning on the inverter. Ignoring the above warning may damage the machine or cause other losses. In this case, the company reserves the right not to carry out the warranty and bear any responsibility and related expenses.</li> </ul>
		<ul> <li>Make sure the cable connector is securely tightened.</li> <li>If the cable connector is not installed correctly, the inverter may be damaged by moisture and dust. All warranty claims are</li> </ul>

# Residual current protection device (RCMU)

Because the inverter itself has a high-precision residual current detection device,it is not recommended to install a leakage protection switch in the system.If for some special reason,it must be installed between the inverter output and the grid.Please install a type B leakage protection switch above 300mA. When multiple leakage protection switches are installed in the system,it is forbidden to share the neutral line,otherwise the leakage protection function may be triggered by mistake and cause the switch to trip.




Fig 5.9 Schematic diagram of inverter wall mounting

#### Preparation before wiring:

Connect the protective ground wire (PE)

Connect the inverter to the grounding bar through the protective earth (PE) to achieve grounding protection.



- > Good grounding is good for resisting surge voltage impact and improving EMI performance. Therefore, you need to ground the wire before connecting the AC,DC, and communication cables.
- > For a single-machine system, only the PE cable needs to be grounded; For a multi-machine system, the PE cables of all inverters need to be connected to the same grounding copper bar to ensure equipotential connection.




Fig 6.1 Grounding diagram

- > Disconnect the inverter DC switch,AC side circuit breaker or switch.
- > Measure the voltage and frequency of the public grid (voltage:AC 230V; frequency:50Hz)

The recommended specifications of the AC output switch are as follows:

Inverter model	Switch specification	Inverter model	Switch specification
MOD 3000TL3-X	10A/230V	MOD 9000TL3-X-AU	20A/230V
MOD 4000TL3-X	10A/230V	MOD 10KTL3-X	25A/230V
MOD 5000TL3-X	15A/230V	MOD 10KTL3-X-AU	25A/230V
MOD 6000TL3-X	15A/230V	MOD 11KTL3-X	25A/230V
MOD 7000TL3-X	15A/230V	MOD 11KTL3-X-AU	25A/230V
MOD 7000TL3-X-AU	15A/230V	MOD 12KTL3-X	25A/230V
MOD 8000TL3-X	20A/230V	MOD 13KTL3-X	30A/230V
MOD 8000TL3-X-AU	20A/230V	MOD 15KTL3-X	30A/230V
MOD 9000TL3-X	20A/230V	/	/

#### AC connection steps:

1. Pass the 5 wires (A,B,C,N and PE wires) through the AC shield,crimp the O/U terminal and connect to the screw terminals on the AC connector.




Fig 6.2 AC output wiring diagram

2.Lock the AC cable to the corresponding AC terminal.




Fig 6.3 Wiring diagram of AC terminal

3. Lock the protective cover on the inverter frame, and finally tighten the protective cover hole.




Fig 6.4 AC quick connection diagram

AC connection steps(just for Vietnam models):

1.Pass the 5 wires (Å,B,C,N and PE wires) through the AC shield,connect them to the power grid, and then crimp the O/U terminal.




Fig 6.5

2.Lock the AC cable to the corresponding AC terminal.




Fig 6.6

3.Lock the protective cover on the inverter frame, and finally tighten the protective cover hole.




Fig 6.7

#### Suggested line length:

Wine near the selection of the selection	Maximum wire length
Wire ross-sectional area	MOD TL3-X series and MOD TL3-X-AU series
6mm²	30m
8 mm²	40m

### 6.3 DC side wiring



Danger

- > Sunlight will generate voltage on the battery panel. The high voltage after the series connection may cause life danger. Therefore, before connecting the DC input cable, you need to cover the battery panel with an opaque material before operation, and ensure the reverse The DC switch of the inverter is in the "OFF" state, otherwise the high voltage of the inverter may cause life danger.
- > To avoid electric shock, do not touch the live parts, and connect the terminals carefully.
- > Please make sure that the AC switch has been disconnected before wiring.

Please ensure that the following conditions are met, otherwise it may cause a fire hazard or damage the inverter. In this case, the company does not carry out quality assurance and assumes any responsibility.

- > The maximum open circuit voltage of each string of photovoltaic modules shall not exceed 1100Vdc under any conditions.
- > PV modules connected in series in each PV string are of the same specification type.
- > The maximum short-circuit current of each PV string must not exceed 26A under any conditions.
- > The total output power of all PV strings must not exceed the maximum input power of the inverter



- input power of the inverter.

  In order to optimize the system configuration, it is recommended to
- connect the two inputs with the same number of photovoltaic modules.
- > If the inverter output is directly connected to the grid (that is, the output side is not connected to a low-frequency isolation transformer), please ensure that the PV string is not grounded.
- > if the inverter input is connected with a specific type of thin-film battery module (PV-grounded), please connect the low-frequency isolation transformer to the output terminal before turning it on, otherwise the inverter will be damaged.
- > If a stable non-zero DC voltage is measured between the positive pole of the photovoltaic string and the ground,it means that an insulation fault has occurred at a certain position in the photovoltaic string. You need to ensure that the fault is repaired before continuing the wiring.


20



Moisture and dust penetration can damage the inverter.

- > Make sure that the waterproof cable gland is firmly tightened.
- > If the cable connector is not installed correctly, the inverter may be damaged due to the penetration of moisture and dust. All warranty claims are void.

The MOD series inverter has two independent inputs, as shown in the figure below:



Fia 6.8

Note: MOD 3-11KTL3-X (2-channel string); MOD 12-15KTL3-X and 7-11KTL3-X-AU(3channel string).

The following points should be concerned when choosing photovoltaic modules:

- > The photovoltaic modules of each photovoltaic string are of the same specification and model.
- > The photovoltaic modules of each photovoltaic string are connected in series with the same number.
  - > Before connecting the battery panel, please make sure that the DC input polarity is correct, that is, the positive pole of the photovoltaic module is connected to the DC input terminal marked "+" of the inverter, and the negative pole is connected to the DC input terminal marked "-".
  - > The maximum DC input current and voltage of the inverter shall not exceed the following limits.



Note

Model	Single maximum input current	Maximum input voltage
MOD 3-11KTL3-X	13A/13A	1100V
MOD 7-11KTL3-X-AU	13A/26A	1100V
MOD 12-15KTL3-X	13A/26A	1100V

#### Connect DC terminal




Fig 6.9

# 6.4 Connect the signal cable

The MOD series inverter has an 16-Pin or 8-Pin signal connector except Vietnam models. The client signal line port is as follows:




Fig 6.10

1.Strip the cable 10mm through the waterproof gland, thread sleeve, and tighten the screws.





Fig 6.11

22

2. Push the threaded sleeve into the socket and tighten the waterproof gland.



3. Connect the client to the inverter plug until both are tightly locked on the inverter.






Fig 6.13

#### Remove the signal connector

1. Press down the fastener and pull it out of the inverter.



2. Insert the H-shaped tool and pull it out of the socket.



# 6.5 Grounding the inverter

The inverter must be connected to the AC grounding conductor of the power distribution grid via the ground terminal (PE) .



Because of the transformerless design, the DC positive pole and DC negative pole of PV arrays are not permitted to be grounded.

This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring.

If an Earth Fault Alarm occurs, the fault code "Error 303,NE abnormal" will be displayed on the inverter screen while the LED indicator red will light up. (Applicable to inverters with graphical display only)




Fig 6.16

According to the relevant provisions of IEC 61643-32 "Connecting to photovoltaic devices surge protectors - selection and use of guidelines", whether for household or commercial photovoltaic power plants, it is necessary to ensure the implementation of lightning protection measures for photovoltaic systems:



WARNING

The lightning protection measures for photovoltaic systems shall be carried out in accordance with the corresponding national standards and IEC standards. Otherwise, photovoltaic devices such as components, inverters and power distribution facilities may be damaged by lightning.

In this case, the company does not carry out warranty and assumes any responsibility.




Fig 6.17

- 1) It is generally recommended to install lightning protection devices (such as lightning rods / lightning protection belts and down conductors) to prevent lightning from hitting the PV array.
- 2) Lightning protection devices and down-conductors and related equipment in photovoltaic systems (including photovoltaic panels, inverters, cables, power distribution equipment) should maintain a safe separation distance S.

Suggested value of S: According to the general 5 storey height (about 15m) building roof, S takes 2.5m enough, the distance S have relationship with the building height.

A. When the safety distance S is satisfied:

The position ①③ of the figure should be equipped with a lightning protection module. In general, it is recommended to install Type II in position ① and Type I in position ③.

- B. When the safety and safety distance S is not met:
- In addition to position 3, Type I lightning protection module should be installed in Figure ①②④.
- 3) The lightning down conductor and the equipment ground wire eventually sink at a total ground point, but the two cannot share the wire. That is, the equipment grounding wire should be pulled separately, and the wire diameter requirement >6mm² when the safety interval distance S is satisfied.
- 4) About the above lightning protection lightning receptor system related design reference GB/T 21714 3-2015.

# 6.6 Active power control with smart meter , CT or ripple control signal receiver



The position of export limitation CT or Meter must between the Inverter & Load and gird.

This series inverter has integrated export limitation functionality. To use this function, you can connect the Growatt smart meter. For the detailed information, please contact with Growatt.





Fig 6.18

Active power control with a Radio Ripple Control Receiver(RRCR).



# 6.7 GFCI(Standard)

#### 6.7.1 Ground Fault Circuit Interrupt(GFCI)

This inverter includes an integrated residual current device . If the leakage current is over 300mA and last for more than 300ms, the inverter will report 201 fault and the OLED will display Residual I High.

The inverter has the function of detecting residual current and protecting the inverter against residual current. If your inverter must equip a AC breaker which has the function of detecting residual current, you must choose a Type A RCD breaker with the rating residual current more than 300mA.

# 6.8 Inverter demand response modes (DRMS)

This series inverter has the function of demand response modes, We use 16-Pin socket as inverter DRMS connection.



#### DRMS application description

- Applicable to AS/NZS4777.2:2015 or Commission Regulation (EU) 2016/631.
- > DRM0, DRM5, DRM6, DRM7, DRM8 are available.



Damage to the inverter due to moisture and dust penetration

- Make sure the cable gland has been tightened firmly.
- ➤ If the cable gland are not mounted properly, the inverter can be destroyed due to moisture and dust penetration. All the warranty claim will be invalid.



Excessive voltage can damage the inverter! External voltage of DRM PORT don't over +5V.

#### 6.8.1 16-Pin socket pin assignment

Pin No.	Assignment for inverters capable of both charging and discharging
9	DRM 5
10	DRM 6
11	DRM 7
12	DRM 8
13	RefGen
14	Com/DRM0
15	NC
16	NC

#### 6.8.2 Method of asserting demand response modes

3.0.2 Method of asserting demand response modes				
Mode	Socket asserted by shorting pins		Function	
DRM 0	14	13	Operate the disconnection device.	
DRM 5	9	13	Do not generate power.	
DRM 6	10	13	Do not generate at more than 50% of rated power.	
DRM 7	11	13	Do not generate at more than 75% of rated power and reduce the reactive power as far as possible.	
DRM 8	12	13	Increase power generation (subject to constraints from other active DRMs).	

#### 6.8.3 Using the Power Control Interface for EU




Fig 6.20 Inverter – RRCR Connection

#### 6.8.3.1 The following table describes the connector pin assignment and function:

DRM Socket Pin NO.	Description	Connect to RRCR
9	Relay contact 1 input	K1 – Relay 1 output
10	Relay contact 2 input	K2 – Relay 2 output
11	Relay contact 3 input	K3 – Relay 3 output
12	Relay contact 4 input	K4 – Relay 4 output
13	GND	Relays common node
14	Not connected	Not connected
15	Not connected	Not connected
16	Not connected	Not connected

#### 6.8.3.2The inverter is preconfigured to the following RRCR power levels:

DRM Socket Pin 9	DRM Socket Pin 10	DRM Socket Pin 11	DRM Socket Pin 12	Active power	Cos(φ)
Short circuit with Pin 13				0%	1
	Short circuit with Pin 13			30%	1
		Short circuit with Pin 13		60%	1
			Short circuit with Pin 13	100%	1

28

Active power control and reactive power control are enabled separately.

### 6.9 AFCI(Optional)

### 6.9.1 Arc-Fault Circuit Interrupter (AFCI)

In accordance with the National Electrical Code R, Article 690.11, the inverter has a system for the recognition of electric arc detection and interruption. An electric arc with a power of 300 W or greater must be interrupted by the AFCI within the time specified by UL 1699B. A tripped AFCI can only be reset manually. You can deactivate the automatic arc fault detection and interruption (AFCI) via a communication product in "Installer" mode if you do not require the function. The 2011 edition of the National Electrical Code R, Section 690.11 stipulates that newly installed PV systems attached to a building must be fitted with a means of detecting and disconnecting serial electric arcs (AFCI) on the PV side.

#### 6.9.2 Danger information



Danger of fire from electric arc

Only test the AFCI for false tripping in the order described below. Do not deactivate the AFCI permanently.

If an "Error 200" message is displayed, the buzzer alarms, an electric arc occurred in the PV system. The AFCI has tripped and the inverter is in permanent shutdown. The inverter has large electrical potential differences between its conductors. Arc flashes can occur through air when high-voltage current flows. Do not work on the product during operation.

When the inverter error 200, please follow the steps:

#### 6.9.3 Operation step

#### 6.9.3.1 Turn the DC & AC Switch to position "OFF".




Fig 6.21

Wait for the screen be off.

# 6.9.3.2 Perform trouble shooting on the PV system:

Check the PV strings' open circuit voltage is normal or not.

# **6.9.3.3** After the fault is rectified, restart the inverter: Turn the DC & AC Switch to position "ON".




Fig 6.22

# Debugging 7

- 1.Close the DC switch on the inverter. As long as the input DC voltage is greater than 140V,the inverter display will show the following information: No mains connection error, the inverter LED will turn red.
- If other information is displayed, please refer to Chapter 13.If you encounter any problems during the debugging process and cannot solve it, please contact customer service.
- 2.Close the circuit breaker or switch between the inverter and the grid, the inverter will start a countdown to the self-check, and after the self-check is normal, it will be connected to the grid.
- 3.In normal operation, the leaves of the inverter indicator window will turn green. 4.Finish debugging.

# 8 Working Mode

#### 8.1 Normal mode

In this mode, the inverter works normally.

- When the DC voltage is greater than 250V, the energy is sufficient, and the grid voltage frequency meets the grid-connected requirements, the inverter will convert the energy of the solar panels into AC power and export to the grid, and the green LED will light up.
- When the DC voltage is lower than 140V, the inverter will automatically disconnect from the grid and exit the normal operation mode. When the input voltage reaches the requirement again and the grid voltage and frequency return to normal, the inverter will automatically connect to the grid.

#### 8.2 Failure mode

The inverter controls the chip monitors and adjusts the state of the system in real time. When the inverter monitors any unexpected conditions, such as system failure and inverter failure, the display will show the fault information. In the failure mode, the inverter will indicate The leaves of the window will turn red and the inverter output will be disconnected from the grid.

#### 8.3 Shutdown mode

When the sunlight is weak or there is no sunlight, the inverter will automatically stop running. When in shutdown mode, the inverter basically does not consume energy from the grid or solar panels, and at the same time, the inverter's display screen and LED lights will be turned off.

# OLED display and touch button 9

The OLED display can display the running status of the inverter, as well as various parameters information, and the display interface of the inverter can be switched and the inverter parameters can be set by touching the button.

Mark	Describe	Explain	
	Touch mark	Single touch	Switch the display interface or the current number plus 1
		Double touch	Enter the setting state or confirm
		Triple touch	Return to the previous display interface
		Long press for 5s	The current data returns to the default value

# 9.1 Boot display

When the inverter is turned on, the OLED display interface is as follows:




Fig 9.1

# 9.2 OLED display wake up

After the inverter works normally for 5 minutes, the OLED display will be automatically turned off. At this time, there is no display on the OLED, and the leaf of the indicator window is green. You need to view the dispaly data or make settings to make the OLED dispaly again through touch operation.

### 9.3 Function setting



The inverter can support multiple touch modes: single touch, two consecutive touches, three consecutive touches, long press for 5S. Different types of taps have different functions. Advanced setting password: 123

All setting interfaces are as follows:




Fig 9.2

#### 9.3.1 Set country

Growatt can provide various regulations of the machine, after customers receive the machine, according to their country, by setting icountry to set the corresponding regulation. Following is the country model introduction.

Country/region / regulations		Country/region / regulations	Model display
Australia	S03XXXXXXXXXXXXX	India	S12XXXXXXXXXXXXX
UK	S08XXXXXXXXXXXX	Brazil	S19XXXXXXXXXXXX
Poland	S27XXXXXXXXXXXX	Hungary	S0CXXXXXXXXXXXX

### 9.3.2 Select the protection voltage level

The factory setting of the inverter is CQC standard regulations. Customers can choose different voltage protection levels according to the actual situation; a single touch switches the voltage level, and two consecutive touches confirm the setting.




Fig 9.3

0 standard

- 1 Wide voltage level 2
- 2 Wide voltage level 3

#### Tips and disclaimers

When the inverter leaves the factory, the grid-connected voltage and frequency are set in accordance with the latest domestic standard;


If the grid voltage is lower or higher than the domestic legal requirements, the inverter cannot be connected to the grid. After obtaining the permission of the local power operator, the user can choose other voltage levels according to the voltage situation of the grid connection point.



Excessive grid voltage may affect the normal use and service life of home appliances on the grid-connected side, or cause loss of power generation. Our company does not accept any responsibility for the related impacts and consequences caused by enabling the automatic control function of output voltage to connect to the grid.

#### 9.3.3 Set language

The default language is English, touch twice in a row to enter the setting mode, a single touch to switch the language, and touch twice to confirm the setting.



#### 9.3.4 Set COM address

The default COM address is 1.Touch twice in a row to enter the setting mode, single touch, the number +1,touch twice in a row to confirm the setting,long press for 5S number to return to zero.




Fig 9.5

#### 9.3.5 Set date and time

Touch twice to enter the parameter setting submenu, select the general setting, touch twice to enter the general setting submenu, single touch to switch the display interface, touch twice in the date and time interface to enter the setting state, single touch, number

34




Fig 9.5

### 9.3.6 Power derating for voltage variation (Volt-Watt mode)

The inverter power output will vary in response to the AC grid voltage. This is switched on by default. This function belongs to advanced function, if you need to change, please contact the after-sales operation and maintenance to make adjustments.

#### 9.3.7 Reactive power regulation for voltage variation (Volt-VAr mode)


The power output or input will vary in response to the AC grid voltage. This function is switched off by default..This function belongs to advanced function, if you need to change, please contact the after-sales operation and maintenance to make adjustments.

# Communication and Monitoring 10

#### 10.1 RS485

This series of inverters provide two RS485 ports. You can monitor one or more inverters via RS485. The other RS485 port is used to connect a smart meter (stand-alone anti-backflow function). The pin function of the 8-core terminal is the same as the 1-8 pin function of the 16-core terminal.

Description	Remarks		
+12V	Dry contact : external relay coil interface, power is not		
СОМ	more than 2W		
RS485A1	Rs485 communication port		
RS485B1	183403 Communication port		
RS485A2	BAT communication		
RS485B2	port(reserved)		
RS485A3	Meter communication port		
RS485B3	Meter communication port		
Relay contact 1 /DRM 5	Relay contact 1 input/DRM5 command		
Relay contact 2 /DRM 6	Relay contact 2 input/DRM6 command		
Relay contact 3 /DRM 7	Relay contact 3 input/DRM7 command		
Relay contact 4/DRM 8	Relay contact 4 input/DRM8 command		
REF/GEN	Relay&DRM signal reference		
DRM0/COM	DRM0 common node		
	+12V  COM  RS485A1  RS485B1  RS485B2  RS485B3  RS485B3  Relay contact 1/DRM 5  Relay contact 2/DRM 6  Relay contact 3/DRM 7  Relay contact 4/DRM 8  REF/GEN		






Fig 10.2 just for Vietnam models

No.	Description	Remarks
1	RS485A1	RS485
2	RS485B1	port
3	RS485A2	Meter communication
4	RS485B2	port


36

#### 10.2 USB-A

USB-A port is mainly used to connect monitoring module or firmware update :

We can connect the external optional monitoring modules, such as Shine WIFI-X, Shine Shine 4G-X, Shine LAN-X, etc. to the USB interface for monitoring.

Steps for installing the monitoring module: Make sure  $\triangle$  is on the front side, then insert the datalogger and tighten the screws.



# 11 Maintenance and Cleaning

### 11.1 Checking Heat Dissipation

If the inverter regularly reduces its output power due to high temperature, please improve the heat dissipation condition. Maybe you need to clean the heat sink.

### 11.2 Cleaning the Inverter

If the inverter is dirty, turn-off the AC breaker and DC switch ,waiting the inverter shut down ,then clean the enclosure lid, the display, and the LEDs using only a wet cloth. Do not use any cleaning agents (e.g. solvents or abrasives).

### 11.3 Checking the DC Disconnect

Check for externally visible damage and discoloration of the DC Disconnect and the cables at regular intervals. If there is any visible damage to the DC Disconnect, or visible discoloration or damage to the cables, contact the installer.

> Once a year, turn the rotary switch of the DC Disconnect from the On position to the Off position 5 times in succession. This cleans the contacts of the rotary switch and prolongs the electrical endurance of the DC Disconnect.

# 12 Start and shut down the inverter

#### 12.1 Start the inverter

Before turning the inverter on, please make sure the PV input voltage and current are within the MPPT limits.

Follow the steps below to turn the inverter on:

- 1. Pull the PV and AC cable make sure there is no loose or shaking.
- 2. Make sure the cable polarity is correct and voltage is less than 1100V
- 3. Switch on the build-in DC isolator at the bottom of the inverter.
- 4. Switch on the PV Array and DC isolator next to your inverter, if you can not find this switch, skip this step.
- 5. Switch on the Solar AC isolator if the inverter is more than 3 meters away from your switchboard.
- 6. Switch on the solar supply main switch in the switch board.

#### 12.2 Shut down the inverter



Don't disconnect the DC connector while the inverter is connected to the  $\operatorname{\sf grid}$  .

Steps to turn off the inverter:

- 1. Disconnect the AC circuit breaker to prevent the inverter from starting again;
- 2. Turn off the DC switch;
- 3. Check the operating status of the inverter;
- 4. Wait until the LED and OLED display are off, indicating that the inverter is turned off.

# Troubleshooting 13

#### 13.1 Error message

When a malfunction occurs, an error message will be displayed on the OLED screen and the LED indicator red will light up. Faults include system faults and inverter faults. In some cases, you may be advised to contact Growatt, please provide the following information.

Information about the inverter: :

- Serial number
- Model
- Error message on OLED
- A short description of the problem
- Grid voltage
- DC input voltage
- •Can you reproduce the failure? If so, how?
- Has this problem occurred in the past?
- •What were the environmental conditions when the problem occurred?

Information about photovoltaic panels:

- •PV panel manufacturer's name and model
- Panel output power
- Voc of the panel
- •Vmp of the panel
- •Imp of the panel
- •The number of panels in each string
- •If you need to replace the device, please ship it to the original box.

## 13.2 System error

#### Warning Code

Warning message	Description	Suggest
Warning 200	String fault	1.After shutdown, Check the panel is normal.     2.If error message still exists, contact manufacturer.
Warning 201	String PID quick connect terminal detection error	After shutdown, Check the string terminal wiring.     If the error message still exists, contact the manufacturer.
Warning 202	DC SPD function abnormal	After shutdown, Check the DC SPD.     If error message still exists, contact manufacturer.
Warning 203	PV Circuit short	1.Check the PV1 or PV2 wiring is short-circuited     2.If error message still exists, contact manufacturer.
Warning 204	Dry contact function abnormal	1.After shutdown, Check the dry Dry contact wiring. 2.If the error message still exists, contact manufacturer.
Warning 205	PV Boost driver broken	Restart inverter.     If error message still exists, contact manufacturer.
Warning 206	AC SPD function abnormal	1.After shutdown, Check the AC SPD.     2.If error message still exists, contact manufacturer.

Warning message	Description	Suggest
Warning 207	U disk over-current protection	1.Unplug the U disk 2.Re-access U disk after shutdown 3.If the error message still exists, contact manufacturer.
Warning 208	DC Fuse Open	1.After shutdown,Check fuse. 2.If error message still exists, contact manufacturer.
Warning 209	exceeding the	1.Immediately disconnect the DC switch and check the voltage 2.If the fault code still exists after the normal voltage is restored, contact manufacturer.
Warning 210	PV Reversed	1.Check PV input terminals     2.If error message still exists, contact manufacturer.
Warning 300	No Utility	1.Please confirm grid is lost or not.     2.If error message still exists, contact manufacturer.
Warning 301	Grid voltage outrange	1. Check the AC voltage is in the range of standard voltage in specification.     2. If error message still exists, contact manufacturer.
Warning 302	Grid frequency outrange	1. Check the frequency is in the range of specification or not.     2. If error message still exists, contact manufacturer.
Warning 303	EPS mode, over load	1.Please reduce the load of EPS output.     2.If error message still exists, contact manufacturer.
Warning 304	CT Open or Wrong	1.Check if AC current sensor is connected well     2.If error message still exists, contact manufacturer.
Warning 305	CT line reversed or Ground fail	1.Check the L line and N line of SP-CT is reversed or not. 2.If error message still exists,contact manufacturer.
Warning 306	Communication fault□ M3 didn't receive SP-CT data	1.Check communication wire     2.If error message still exists, contact manufacturer.
Warning 307	Communication fault	1.Check communication wire.     2.If error message still exists, contact manufacturer.
Warning 400	Fan function abnormal	1.After shutdown,Check the fan connection.     2. replace the fan.     3.If the error message still exists, contact manufacturer.

Warning message	Description	Suggest
Warning 401	Meter abnormal	1.Check if the meter is on 2.Check the machine and the meter connection is normal.
Warning 402	Optimizer and inverter communication is abnormal	1.Check if the optimizer is on.     2.Check whether the connection between the optimizer and the inverter is normal.
Warning 403	String communication abnormal	1. After shutdown, Check the string panel wiring. 2. If the error message still exists, contact manufacturer.
Warning 404	EEPROM abnormal.	1.Restart inverter. 2.If error message still exists, contact manufacturer.
Warning 405		1.Check the firmware version.     2.If error message still exists, contact manufacturer.
Warning 406	Boost module error	1.Restart inverter 2.If error message still exists, contact manufacturer.

# 13.3 System error

Error code	Description	Suggest
Error 200	AFCI Fault	1.After shutdown,Check the panel terminal.     2.Restart inverter.     3.If error message still exists,contact manufacturer.
Error 201	Leakage current too high.	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 202	The DC input voltage is exceeding the maximum tolerable value.	1.Immediately disconnect the DC switch and check the voltage 2.If the fault code still exists after the normal voltage is restored, contact manufacturer
Error 203	PV isolation Low	1.After shutdown, check whether the panel shell is reliably grounded.     2.If error message still exists, contact manufacturer.
Error 300	AC V Outrange	1.Check grid voltage. 2.If the error message still exists despite the grid voltage being within the tolerable range, contact manufacturer.
Error 301	AC terminals reversed	1.Check AC terminals     2.If error message still exists, contact manufacturer.
Error 302	No AC Connection	After shutdown, Check AC wiring.     If error message still exists, contact manufacturer.
Error 303	NE abnormal	1.Check PE, to ensure that the PE line contact good.     2.If error message still exisits, contact Manufacturer.
Error 304	AC F Outrange	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 305	Over Load Fault	1.Check whether output load over range; If load too large, please reduce load 2.If error message still exists, contact manufacturer.
Error 306	CT LN Reversed	1.After shutdown□ Check the SP-CT connection. 2.If error message still exists,contact manufacturer.
Error 307	Communication fault□ M3 didn't receive SP-CT data	1.Check communication wire     2.If error message still exists, contact manufacturer.
Error 308	Communication fault;Pairing time too long	1.Restart pairing     2.If error message still exists, contact manufacturer.

Error code	Description	Suggest
Error 400	DCI bias abnormal	1.Restart inverter     2.If error message still exists, contact manufacturer.
Error 401	DC Voltage High Fault	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 402	Output DC current too high.	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 403	Output current unbalance	1.After shutdown,Check the output current is not balanced.     2. If the error message still exists, contact manufacturer
Error 404	bus sample fault	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 405	Relay fault	Restart inverter.     If error message still exists, contact manufacturer.
Error 406	Init model fault	Reset mode     Il error message still exists, contact manufacturer.
Error 407	AutoTest failure	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 408	NTC Temperature too high	1.After shutdown,Check the temperature, normal restart the inverter 2. If the error message still exists, contact manufacturer
Error 409	Bus voltage abnormal	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 410	Communication board and control panel sampling battery voltage is inconsistent	1.Restart inverter     2.If error message still exists, contact manufacturer.
Error 411	Communication fault	1.After shutdown,Check communication board wiring     2. If the error message still exists, contact manufacturer
Error 412		1.After shutdown, Check the temperature sampling module is connected properly     2.If the error message still exists, contact manufacturer

Error code	Description	Suggest
Error 413	IGBT drive fault	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 414	EEPROM fault	1.Restart inverter     2.If error message still exists, contact manufacturer.
Error 415	Internal power test fail(PV Power low)	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 416	Over current protected by software	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 417	The grid voltage sampling is inconsistent	1.Restart the machine; 2.If the fault information still exists,contact the manufacturer.
Error 418	DSP and COM firmware version unmatch	1.Check the firmware version. 2.If error message still exists, contact manufacturer.
Error 419	Inconsistent leakage current sampling	1.Restart the machine; 2.If the fault information still exists,contact the manufacturer.
Error 420	GFCI Module damage	1: After shutdown, Check the leakage current module 2: If the error message still exists, contact manufacturer
Error 421	CPLD is abnormal	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 422	s a m p l i n g i s inconsistent	1.Restart inverter.     2.If error message still exists, contact manufacturer.
Error 425	AFCI self-test fault	1.Restart inverter     2.If error message still exists, contact manufacturer.

# Manufacturer warranty 14

Please refer to the warranty card.

# **Decommissioning 15**

# 15.1 Dismantling the Inverter

- 1. Disconnect the inverter as described in section8.
- 2. Remove all connection cables from the inverter.



Danger of burn injuries due to hot enclosure parts!

Wait 20 minutes before disassembling until the housing has cooled down.

- 3. Screw off all projecting cable glands.
- 4. Lift the inverter off the bracket and unscrew the bracket screws.

### 15.2 Packing the Inverter

If possible, always pack the inverter in its original carton and secure it with tension belts. If it is no longer available, you can also use an equivalent carton. The box must be capable of being closed completely and made to support both the weight and the size of the inverter.

# 15.3 Storing the Inverter

Store the inverter in a dry place where ambient temperatures are always between -25°C and +60°C.

# 15.4 Disposing of the Inverter



Do not dispose of faulty inverters or accessories together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner

# 16 EU Declaration of conformity

With the scope of EU directives:

- •2014/35/EU Low Voltage Directive (LVD)
- •2014/30/EU Electromagnetic Compatibility Directive (EMC)
- •2011/65/EU RoHS Directive and its amendment (EU)2015/863

Shenzhen Growatt New Energy Technology Co. Ltd confirms that the Growatt inverters and accessories described in this document are in compliance with the above mentioned EU directives. The entire EU Declaration of Conformity can be found at www.ginverter.com.

# **Specification 17**

### 17.1 Parameter

Model Specifications	MOD 3000TL3- X	MOD 4000TL3- X	MOD 5000TL3- X	MOD 6000TL3- X	MOD 7000TL3- X	MOD 8000TL3- X	
Input data(DC)							
Max. recommended PV power(for module STC)	4500W	6000W	7500W	9000W	10500W	12000W	
Max. DC voltage			110	)0V			
Start voltage			20	0V			
Nominal voltage			58	0V			
MPP voltage range			140-1	000V			
No. of MPP trackers			2	2			
No. of PV strings per MPP trackers	1/1	1/1	1/1	1/1	1/1	1/1	
Max. input current per MPP trackers	13/13A	13/13A	13/13A	13/13A	13/13A	13/13A	
Max. short-circuit current per MPP trackers		16/16A					
Backfeed current to PV array	0A						
Output data(AC)							
AC nominal power	3000W	4000W	5000W	6000W	7000W	8000W	
Max. AC apparent	3300VA	4400VA	5500VA	6600VA	7700VA	8800W	
Nominal AC voltage/range			230/	400V			
AC grid frequency/range				0 Hz /55-65 Hz			
Max. output current	5.0A	6.7A	8.3A	10.0A	11.7A	13.3A	
AC inrush current			3(	λ			
Max. output fault current		24.	.6A		44	.5A	
Max. output overcurrent Protection		24.	.6A		44	.5A	
Power factor(@nominal power)		>0.99					
Adjustable power factor	0.8Leading0.8Lagging						
THDi	<3%						
AC grid connection type			3W+PE/3	BW+N+PE			
Efficiency							
Max. efficiency		98.	3%		98.	6%	
Euro-eta			97	'%			

Model	MOD 3000TL3-	MOD 4000TL3-	MOD 5000TL3-	MOD 6000TL3-	MOD 7000TL3-	MOD 8000TL3-			
Specifications	X	X	X	X	X	X			
Protection devices									
DC reverse-polarity protection		YES							
DC switch			Υ	ES					
DC Surge protection			typel	I OPT					
Insulation resistance monitoring			Υ	ES					
AC surge protection			typel	IOPT					
AC short-circuit protection			Υ	ES					
Grid monitoring			Υ	ES					
Anti-islanding protection			Υ	ES					
Residual-current monitoring unit			Υ	ES					
String Fuse protection			N	0					
String monitoring			0	PT					
AFCI protection			0	PT					
General data									
Dimensions (W / H / D) in mm		425*387	*147mm		425*387	* 178mm			
Weight		12.	5kg		14	łkg			
Operating temperature range				. +60°C Perating)					
Noise emission (typical)			≤350	dB(A)					
Altitude			400	00m					
Internal consumption at night			1	W					
Topology			Transfo	rmerless					
Cooling		ı	Natural hea	t dissipation	n				
Electronics protection degree			IP	66					
Relative humidity			0~1	00%					
DC connection	H4/MC4(OPT)								
AC connection	Waterp	roof PG he	ad+OT term	inal or quic	k connect t	erminal			
Interfaces									
Display			OLED	+LED					
USB/RS485			Υ	ES					
WIFI/GPRS/4G/RF/LAN			0	PT					

Model Specifications	MOD 9000TL3-X	MOD 10TL3-X	MOD 11TL3-X	MOD 12TL3-X	MOD 13TL3-X	MOD 15TL3-X	
Input data(DC)	-		1	1			
Max. recommended PV power(for module STC)	13500W	15000W	16500W	18000W	19500W	22500W	
Max. DC voltage			110	)0V			
Start voltage			20	0V			
Nominal voltage			58	0V			
MPP voltage range			140-1	000V			
No. of MPP trackers			2	2			
No. of PV strings per MPP trackers	1/1	1/1	1/1	1/2	1/2	1/2	
Max. input current per MPP trackers	13/13A	13/13A	13/13A	13/26A	13/26A	13/26A	
Max. short-circuit current per MPP trackers	16/16A	16/16A	16/16A	16/32A	16/32A	16/32A	
Backfeed current to PV array			0	A			
Output data(AC)							
AC nominal power	9000W	10000W	11000W	12000W	13000W	15000W	
Max. AC apparent	9900VA	11000VA	12100VA	13200VA	14300VA	165000VA	
Nominal AC voltage/range			230/	400V			
AC grid frequency/range			50/6 45~55Hz/	0 Hz /55-65 Hz			
Max. output current	15A	16.7A	18.3A	20.0A	21.7A	25A	
AC inrush current			30	)A			
Max. output fault current		44.5A			58.4A		
Max. output overcurrent Protection		44.5A			58.4A		
Power factor(@nominal power)			>0	.99			
Adjustable power factor		0.	8Leading .	0.8Laggir	ng		
THDi			<3	%			
AC grid connection type		3W+PE/3W+N+PE					
Efficiency							
Max. efficiency			98.	6%			
Euro-eta			97	%			

Model Specifications	MOD 9000TL3-X	MOD 10KTL3-X	MOD 11KTL3-X	MOD 12KTL3-X	MOD 13KTL3-X	MOD 15KTL3-X			
Protection devices									
DC reverse-polarity protection		YES							
DC switch			YE:	S					
DC Surge protection			typell	OPT					
Insulation resistance monitoring			YE:	S					
AC surge protection			typell	OPT					
AC short-circuit protection			YE:	S					
Grid monitoring			YE:	5					
Anti-islanding protection			YE:	S					
Residual-current monitoring unit			YE:	S					
String Fuse protection			NC	)					
String monitoring			OP.	Т					
AFCI protection			OP.	Т					
General data									
Dimensions (W/H/D) in mm			425*387*	178mm					
Weight		14kg			16.0kg				
Operating temperature range			-25°C (>45°CDe						
Noise emission (typical)			≤35dE	3(A)					
Altitude			4000	)m					
Internal consumption at night			1 W	I					
Topology			Transforr	merless					
Cooling		1	Natural heat	dissipation					
Electronics protection degree			IP6	6					
Relative humidity			0~10	0%					
DC connection			H4/MC4	(OPT)					
AC connection	Water	proof PG hea	ad+OT termii	nal or quick	connect ter	minal			
Interfaces									
Display			OLED+	-LED					
USB/RS485			YE:	S					
WIFI/GPRS/4G/RF/LAN			OP.	Т					

### Australian models

Model Specifications	MOD 3000TL3- X	MOD 4000TL3- X	MOD 5000TL3- X	MOD 6000TL3- X	MOD 7000TL3- X-AU	MOD 8000TL3- X-AU
Input data(DC)						
Max. recommended PV power(for module STC)	4500W	6000W	7500W	9000W	10500W	12000W
Max. DC voltage			110	00V		
Start voltage			20	0V		
Nominal voltage			58	0V		
MPP voltage range			140-1	1000V		
No. of MPP trackers			:	2		
No. of PV strings per MPP trackers	1/1	1/1	1/1	1/1	1/2	1/2
Max. input current per MPP trackers	13/13A	13/13A	13/13A	13/13A	13/26A	13/26A
Max. short-circuit current per MPP trackers		16/16A 16/32A				
Backfeed current to PV array		0A				
Output data(AC)						
AC nominal power	3000W	4000W	5000W	6000W	7000W	8000W
Max. AC apparent	3000VA	4000VA	5000VA	6000VA	7000VA	8000W
Nominal AC voltage/range			230/	400V		
AC grid frequency/range				60 Hz /55-65 Hz		
Max. output current	4.5A	6.0A	7.6A	9.1A	10.6A	12.1A
AC inrush current			3(	DΑ		
Max. output fault current		24	.6A		44.	.5A
Max. output overcurrent Protection		24	.6A		44.	.5A
Power factor(@nominal power)			>0	.99		
Adjustable power factor	0.8Leading0.8Lagging					
THDi	<3%					
AC grid connection type		3W+PE/3W+N+PE				
Efficiency						
Max. efficiency		98.	3%		98.	6%
Euro-eta			97	7%		

Model	MOD 3000TL3-	MOD 4000TL3-	MOD 5000TL3-	MOD 6000TL3-	MOD 7000TL3-	MOD 8000TL3-			
Specifications	X	X	X	X	X-AU	X-AU			
Protection devices									
DC reverse-polarity protection		YES							
DC switch		YES							
DC Surge protection			typel	I OPT					
Insulation resistance monitoring			YI	ES					
AC surge protection			typel	I OPT					
AC short-circuit protection			YI	ES					
Grid monitoring			YI	ES					
Anti-islanding protection			YI	ES					
Residual-current monitoring unit			YI	ES					
String Fuse protection			N	0					
String monitoring			0	PT					
AFCI protection			0	PT					
General data									
Dimensions (W / H / D) in mm		425*387	*147mm		425*387	'* 178mm			
Weight		12.	5kg		16.	16.0kg			
Operating temperature range				. +60°C Perating)					
Noise emission (typical)			≤350	dB(A)					
Altitude			400	00m					
Internal consumption at night			1'	W					
Topology			Transfo	rmerless					
Cooling		1	Natural hea	t dissipatio	n				
Electronics protection degree			IP	66					
Relative humidity			0~1	00%					
DC connection			H4/MC	4(OPT)					
AC connection	Waterp	proof PG hea	ad+OT term	inal or quic	k connect t	erminal			
Interfaces									
Display		OLED+LED							
USB/RS485			YI	ES					
WIFI/GPRS/4G/RF/LAN			0	PT					

Model Specifications	MOD 9000TL3- X-AU	MOD 10TL3-X- AU	MOD 11TL3-X- AU	MOD 12TL3-X	MOD 13TL3-X	MOD 15TL3-X	
Input data(DC)	1						
Max. recommended PV power(for module STC)	13500W	15000W	16500W	18000W	19500W	22500W	
Max. DC voltage			110	)0V			
Start voltage			20	0V			
Nominal voltage			58	0V			
MPP voltage range			140-1	000V			
Full-load voltage range	320-850V	400-8	350V	480-	-850V	520-850V	
No. of MPP trackers			2	2			
No. of PV strings per MPP trackers	1/2	1/2	1/2	1/2	1/2	1/2	
Max. input current per MPP trackers	13/26A	13/26A	13/26A	13/26A	13/26A	13/26A	
Max. short-circuit current per MPP trackers	16/32A	16/32A	16/32A	16/32A	16/32A	16/32A	
Backfeed current to PV array			0	А			
Output data(AC)							
AC nominal power	9000W	10000W	11000W	12000W	13000W	15000W	
Max. AC apparent	9000VA	10000VA	11000VA	12000VA	13000VA	150000VA	
Nominal AC voltage/range			230/4	400V			
AC grid frequency/range			50/6 45~55Hz/				
Max. output current	13.6A	15.2A	16.7A	18.2A	19.7A	22.7A	
AC inrush current			30	)A			
Max. output fault current		44.5A			58.4A		
Max. output overcurrent Protection		44.5A			58.4A		
Power factor(@nominal power)			>0	.99			
Adjustable power factor		0.8Leading0.8Lagging					
THDi	<3%						
AC grid connection type	3W+PE/3W+N+PE						
Efficiency							
Max. efficiency			98.	6%			
Euro-eta			97	%			

Model Specifications	MOD 9000TL3- X-AU	MOD 10KTL3- X-AU	MOD 11KTL3- X-AU	MOD 12KTL3-X	MOD 13KTL3-X	MOD 15KTL3-X				
Protection devices						1				
DC reverse-polarity protection			YI	ES						
DC switch		YES								
DC Surge protection			typel	I OPT						
Insulation resistance monitoring			YI	ES						
AC surge protection			typel	I OPT						
AC short-circuit protection			YI	ES						
Grid monitoring			YI	ES						
Anti-islanding protection			YI	ES						
Residual-current monitoring unit			YI	ES						
String Fuse protection			N	0						
String monitoring			0	PT						
AFCI protection			0	PT						
General data										
Dimensions (W / H / D) in mm			425*387	* 178mm						
Weight			16.	0kg						
Operating temperature range			-25°C (>45°CD							
Noise emission (typical)			≤350	dB(A)						
Altitude			400	00m						
Internal consumption at night			11	W						
Topology			Transfo	rmerless						
Cooling			Natural hea	t dissipation						
Electronics protection degree			IP	66						
Relative humidity			0~1	00%						
DC connection			H4/MC	4(OPT)						
AC connection	Water	proof PG he	ad+OT term	inal or quick	connect ter	minal				
Interfaces										
Display			OLED	+LED						
USB/RS485			YI	ES						
WIFI/GPRS/4G/RF/LAN			0	PT						

# 17.2 Torque

Shell cover screw	22kgf.cm
AC terminal block	8kgf.cm
AC waterproof cover fixing screw	8kgf.cm
Security screws on the wall mount	12kgf.cm
Ground screw	12kgf.cm

### 17.3 Annex

Product attachments can be selected from the table below:



The monitoring equipment is not standard, it needs to be purchased separately. As for detailed installation and use methods, please refer to its own manual.

Name	Brief
Shine GPRS-X	USB interface GPRS monitoring module
Shine WIFI-X	USB interface WIFI monitoring module
Shine 4G-X	USB interface 4G monitoring module
Shine RF-X	USB interface RF monitoring module
Shine LAN-X	USB interface LAN monitoring module

The inverter can be repaired on site or transported to the Growatt service center for repair, or it can be replaced with a new one based on the model and service life of the machine.

The warranty does not include the cost of recovery and transportation of faulty equipment. The cost of installation or reinstallation of malfunctioning equipment should also be clearly excluded from other related logistics and processing costs incurred by warranty claims related to various aspects.

# 18 Compliance certificates

With the appropriate settings, the unit will comply with the requirements specified in the following standards and directives (dated: Dec./2018):

Model	Certificates
\/ () )	CE,IEC 62109,INMETRO,AS 4777.2,EN50549,N4105,C10/11, IEC 62116/61727,IEC 60068/61683
MOD 3-6KTL3-X MOD 7-11KTL3-X-AU MOD 12-15KTL3-X	IEC 62109,AS 4777.2

# Contect us 19

56

If you have technical questions about our products, please contact the Growatt New Energy Service Hotline. We need the following information to provide you with the necessary help:

- Inverter type
- Inverter serial number
- > Inverter error message code
- > Inverter OLED display content
- > Type and number of PV modules connected to the inverter
- Inverter communication method

#### Shenzhen Growatt New Energy CO.,LTD

No.28 Guangming Road, Shiyan Street, Bao'an District, Shenzhen, P.R.China

T +86 755 2747 1942

E service@ginverter.com

w www.ginverter.com